





Exposed part for concealed washbasin mixer SMOOTH X32_X3013511

MODEL **X3013511**

Exposed part for concealed washbasin mixer, without concealed part, for item ZA033510, with smooth handles, Inox AISI 316L


AVAILABLE FINISHINGS

-  **5H** 5H Dark Brass Brushed
-  **5L** 5L Brushed Black Titanium
-  **5N** 5N Brushed Rose Gold
-  **D1** D1 Brushed Inox


CHARACTERISTICS

Installation **Concealed**

Required concealed parts **ZA033510**



Exposed part for concealed washbasin mixer SMOOTH X32_X3013511



X3013511


<https://en.cisal.it/exposed-part-for-concealed-washbasin-mixer-smooth-x32-x3013511>

Concealed washbasin mixer CONCEALED_ZA033510

MODEL **ZA033510**


Concealed washbasin mixer, with two right headvalves

AVAILABLE FINISHINGS

 **04** 04 Without finishing

CHARACTERISTICS

Concealed **1**



2025-01-09