

Single lever washbasin mixer EnergySave ALMA\_A3000475



MODEL A3000475

Single lever washbasin mixer EnergySave, with automatic 1"1/4 automatic pop-up waste, G.3/8" stainless steel flexible hoses

## AVAILABLE FINISHINGS




21 21 Chrome



**2F** 2F Brushed Nickel



## 40 40 Matt Black



## CHARACTERISTICS

## Cartridge Spare Parts

ZZ95409000

### 35 mm Cartridge



## EcoStop

EcoStop feature limits water flow to approximately 50% of maximum output with one point of resistance on setting. Push slightly past the middle stop only when full water output is required. This will save water up to 50%.




## EnergySave

Thanks to the EnergySave device, only cold water will be drawn if the lever is operated in the central position, so that the water heater will not be engaged and no hot water wasted, leading to considerable savings in energy and costs. The temperature can be adjusted by rotating the lever to the left, until the desired temperature is reached.



## Single lever washbasin mixer EnergySave ALMA\_A3000475



A3000475

<https://en.cisal.it/single-lever-washbasin-mixer-energysave-alma-a3000475>

2026-01-11