


Exposed part for concealed washbasin mixer SMOOTH X32_X4013511




X4013511

https://en.cisal.it/exposed-part-for-concealed-washbasin-mixer-smooth-x32x4013511



Concealed washbasin mixer CONCEALED_ZA033510



ZA033510

https://en.cisal.it/concealed-washbasin-mixer-concealedza033510